ACCE. 160082

UDI-DI 872026126SIGHTTANDEM9J

User Manual

Nindo



NIJLAND

nijland.com

Nijland Cycling, User Manual 2026

Branding & Design
Studio Debuut

Production
Raoul Alferink

Photography
Melvin Winkeler

Editorial
Nijland Cycling

Risk Class:	1
Issue Date:	01-01-2026
Version:	1
Language:	English

Nindo

	Model	EAN:
	Nindo	8720261260228
	Nindo E 250W	8720261260525
	Nindo E 500W	8720261260235

© 2026 Nijland Cycling. All rights reserved. All information and prices in this brochure are subject to change and possible printing errors. No part of this publication may be reproduced without written permission.

Table of Contents

04

Information

Introduction 4
Contact Details 5
Compliance 5
First Use 5
Usage 5

06

Management

Tips 6
Maintenance 6
Safety 7
Prevent Theft 8

08

Components

Lighting 8
Tires 9
Brakes 9
Saddle 9
Handlebar 10
Gears 10
Lock 11
Differential 11
Luggage Carrier 11
Environment 12
Transport and Storage 12

13

Documentation

Dimensions 13
Specifications 14
Warranty 15
Warranty Certificate 15
Service, Maintenance, and Modification Form 16
Maintenance History 17
Notes 18



Introduction

This manual provides important information regarding the use of the Nindo. We recommend that you read it carefully before using the bicycle for the first time. Doing so will help you become familiar with the main components and learn how to ride safely and comfortably.

It is important to follow the instructions in this manual. This not only ensures your own safety but also the safety of others. In addition, it helps keep your bicycle in good condition and allows you to enjoy it to its fullest potential.

Keep this manual in a convenient place so that you can consult it whenever necessary. For the latest version, please contact Nijland Cycling. We will ensure that you always have access to the most up-to-date information.

We hope you enjoy many pleasant rides on your Nindo. Enjoy every journey, knowing that you are well prepared.

Kind regards,

Team Nijland Cycling

Contact details

Nijland Cycling B.V.
Telgenweg 12
8111 CM Heeten

+31(0)572 382 222

info@nijland.com

www.nijland.com

Conformity

As the manufacturer, Nijland Cycling declares that the Nindo is produced in accordance with the MDR regulation (EU) 2017/745, risk class 1. The electric model complies with Directive 2006/42/EC, the EMC Directive 2014/30/EU, and NEN-EN 15194:2017 Bicycles - Electrically power assisted cycles - EPAC Bicycles - part 4.2 Electrical requirements. The declaration of conformity is available from the manufacturer.

First Use

Your dealer should review the following points with you:

1. Ensure the bike is properly adjusted to your body height and weight.
2. Practice in a calm environment to get familiar with the bike and develop proper control.
3. Practice using the hand brakes on different types of surfaces.
4. Try riding at different speeds and learn how to maintain balance.
5. Take your time to get used to the bike and gradually increase the length of your rides.
6. Regularly check the bike to make sure everything works correctly and is properly adjusted.

Dealer's Initials: _____ **Date:** _____

Use

The Nindo tandem is designed for two people, where one rider is a child sitting in the front. The other rider can be an adult, who may have reduced mobility, stability, coordination, or other limitations in their natural physical movements. Depending on the situation, supervision may be required during use. When the child or the rider has a limited mental perception capacity, it is important that a supervisor provides clear instructions regarding the safe use of the tandem. The adult rider must be independently mobile and capable of participating in traffic responsibly, while observing the applicable traffic rules. It is essential that the instructions in this manual are strictly followed. Using the Nindo tandem in any way other than described herein falls outside the responsibility of Nijland Cycling.



Management

Tips

- Never use a high-pressure cleaner for cleaning, as the water can remove grease and cause moving parts to wear out faster. Instead, use a clean cloth.
- Never lubricate the brakes, as this can reduce their effectiveness.
- If you or your dealer adjusts the height of the handlebar or saddle, make sure the safety marking is never visible.
- Ensure you are clearly visible to other road users while riding the bike.
- We recommend taking out bicycle insurance.

Maintenance

You are personally responsible for the maintenance of your bicycle. We recommend having repairs and service carried out by your dealer. To enjoy your bicycle for a long time, it is very important to check the following points regularly:

Monthly:
Check the tire pressure, the operation of the lights, and whether the brakes function correctly every month. Check if the pedals and cranks are firmly attached, that there is no play in the headset, that the spoke tension is correct, that the wheels show no runout (wobble), and that the seat post and handlebar stem are securely tightened.

Semi-annually:
Grease the seat post and handlebar stem, check if the wheel axles are securely fixed, and ensure the mounting bolts are tightly fastened. Check the headset for play, retighten the screws of the saddle and handlebars, and apply grease to the pedal axle.

Annually:
Have your bicycle checked by your dealer at least once a year for the following points: drivetrain, frame, front fork, wheel suspension, lighting, spoke tension, brakes, and bearings. Also check the rims for deformation, cracks, and rust formation.

At the back of this manual, you will find a maintenance history where all performed work is recorded.
Please note: The parts replaced during maintenance must be of the same brand and type as those used by Nijland Cycling. It is not permitted to use other parts for this purpose.

> ***Note:*** *The parts replaced during maintenance must be of the same brand and type as those used by Nijland Cycling. It is not permitted to use other parts for this purpose.*

Safety

Safety comes first. Therefore, please observe the following points to ensure a safe and enjoyable ride:

- Ensure that the sizing of the bicycle is adjusted to you as the user.
- Ensure that the bicycle is in good condition each time before it is used.
- Before every ride, check the correct operation of the brakes, the correct operation of the lights, and ensure there is sufficient air in the tires.
- Regularly check whether the wheels, handlebars, and saddle are securely fastened, and also whether all screw connections are tightly secured.
- Use the Nindo on a surface that is as solid and flat as possible.
- Take potholes and uneven surfaces into account, and adjust your speed accordingly.
- Be careful that wide trousers, flapping garments, and loose shoelaces do not get caught in the chain, spokes, or pedals.
- Do not use a high-pressure or steam cleaner for cleaning.
- Always lock the Nindo when leaving the bicycle unattended.
- Ensure that dangerous speeds do not develop during descents. Brake in time and adjust your speed to the conditions.
- Keep in mind that the braking distance is significantly longer on wet road surfaces during bad weather.
- Extra caution is required during pregnancy due to an increased risk of injury.
- Do not place the bicycle in direct sunlight: the temperature of some parts can pose a risk. Coming into contact with the skin may potentially cause skin hypersensitivity.
- For the electrically assisted Nindo: Take time to get used to the functions of the pedal assistance. Always pay close attention when switching on the assistance. Practice accelerating with the electric motor.
- Have the bicycle inspected after an accident or incident, even if there is no visible damage.
- Always carry a mobile phone and ensure you have your dealer's telephone number in your contacts.
- Ensure that you always set off well-prepared.
- Be careful when taking sharp/right-angle turns and crossing speed bumps; adjust your speed accordingly.

Extra attention is required if a child is using the bike:

- Never leave a child alone with the bike without supervision.
- Always have the child wear a properly fitting bicycle helmet.
- Have the child wear bright, reflective clothing so they are clearly visible to other road users.
- It is recommended to attach a small flag to the bike, extending above the child for added visibility.

Installation of accessories

- The installation of accessories is only permitted when the bicycle is specified as suitable for this according to the product specifications. Always follow the installation, usage, and safety instructions provided by the manufacturer of the relevant accessory, and ensure that installation is carried out by a qualified professional.
- When using a child seat in combination with a suspension saddle, there is a risk of finger entrapment. Check the safety of this combination or replace the saddle if necessary.

Note: Installed accessories may affect the riding characteristics of the bicycle.

Prevent Theft

- Always lock your bike.
- If using a cable lock, secure your bike to a fence or post. If the cable is long enough, pass it through the frame and front wheel.
- Every bike has a unique frame number, which can be found on the frame sticker located on the seat tube.

Frame number: _____



Components

Lighting

On the electrically assisted Nindo, the lighting is connected to the battery. This means you can turn on the lights by pressing and holding the (+) button for a few seconds. The front and rear lights will turn on simultaneously. If you want to turn the lights off again, press and hold the (+) button for a few seconds once more. The non-electrically assisted Nindo is equipped with battery-powered lighting. You can switch the headlight on and off by pressing the power button on the headlight. You can switch the taillight on and off by pressing the power button on the taillight.

Tires

If your tires are not at the correct pressure, they will wear out faster. Therefore, we recommend regularly checking whether your tires are at the correct pressure. The tires are at the correct pressure when you can just barely press them in slightly with your thumb. Riding on firm tires is much more pleasant, as you need to apply less force to the pedals. Correct tire pressure also makes steering easier. The recommended bar (tire pressure) can be found on the tires of your bicycle or in the Dimensions chapter at the back of this user manual.

Brakes

The brakes are among the most important components of your bicycle. Use both brakes as much as possible to reduce your speed. Always check whether the brakes work properly before you set off. If you notice that the brake levers must be pulled (almost) against the handlebar grip before the bicycle slows down, the brakes must be readjusted or the brake pads must be replaced. The bicycle is equipped with a freewheel hub. With a freewheel hub, you have two brake levers on the handlebars. The left brake lever is for the front brake, and the right brake lever is for the rear brake.

Saddle

When you sit on the saddle, it is adjusted to the correct height if you can place your shoe flat on the ground. The angle of the saddle can be adjusted by opening the quick release and loosening the bolt with a wrench. The height can be adjusted by opening the lever (Figure 1). After adjusting the saddle, the clamp and the bolt must be securely tightened.

> *Note: The safety marking on the seat post must not be visible when the saddle is inside the seat tube (Figure 2).*



1 Saddle adjustment system



2 Height marking

Handlebars

The height of the handlebars can be adjusted. By gently pushing the display upwards, the expander bolt becomes visible. Loosen it using a wrench; now you can push the handlebars up or down. After adjustment, securely tighten the expander bolt again (Figure 3).

> ***Note:*** *The safety marking on the handlebar stem must not be visible when the handlebars are inside the head tube (Figure 4).*



3 Loosen the bolt with a wrench



4 Height marking

Gears

If your Nindo has gears, a gripshift (gear shifter) is present on your handlebars (Figure 5).

When you turn it towards the +, pedaling becomes heavier.
When you turn it towards the -, pedaling becomes lighter.



5 Gripshift

Lock

The Nindo is equipped with a safety ring lock (Figure 6).
The safety lock can be operated as follows:

1. Turn the key in the lock clockwise.
2. Push the lever down so that the lock engages and locks the rear wheel.
3. Turn the key in the lock counterclockwise and remove the key from the lock.

You can unlock the wheel by inserting the key into the lock and turning it clockwise.



6 Ringlock

Accessories

Various accessories are available for your Nindo or Nindo E; please inquire with your dealer for more information.

Luggage Carrier

The luggage carrier can be used for small bags or other objects (Figure 7). The load on the luggage carrier must not exceed 25 kilograms.



7 Luggage carrier

Environment

A defective, leaking, dropped, or deformed battery must be replaced immediately. The old battery must be handed in to the dealer or the local municipal recycling center.

Transport and Storage

- If you transport the Nindo by vehicle, ensure this is done safely.
- It is prohibited to transport anyone on the Nindo while it is being transported.
- We recommend storing the Nindo in a dry place at all times.
- When the bicycle is stored for an extended period, you must check the tire pressure before use. The tire pressure must correspond to the values specified by the manufacturer.
- It is important that you read the user manual for your battery, especially if your bicycle stands idle for a long period. This is in connection with discharge voltages.
- Before storing the bicycle for a long period, we recommend cleaning it.



Details

Dimensions



	Nindo
Total length:	238 cm
Total width:	79 cm
Weight:	45 kg
Suitable inside leg length front side:	51 - 71 cm
Suitable inside leg length rear side:	72 - 100 cm
Crank length:	12 cm / 15 cm
Maximum load:	180kg
Entry height:	32 cm
Max. permissible weight luggage carrier:	25 kg
Tire size front:	20 x 1.75 inch
Tire size rear:	26 x 1.75 inch
Tire pressure:	Front: 3.5 - 5 bar / Rear: 3 - 5 bar

Specificaties

Frame:	Steel frame with 2-layer powder coat finish
Color:	Titan grey, Night blue or custom RAL color
Electrical system:	Bafang 250W front wheel motor
Battery:	Removable 468Wh battery, 612Wh battery optional
Lighting:	Connected to battery on electric model, battery-powered on non-electric model
Drive system:	7-speed Freewheel
Chain guard:	Closed chain guard
Handlebars:	Chrome-plated metal handlebars
Seat:	Adjustable seat angle and seat height
Wheels:	Ground rims with stainless steel spokes
Fenders:	Black coated aluminum
Tires:	Schwalbe Marathon Plus
Pedals:	Plastic non-slip pedals
Cranks:	Black steel cranks
Front brakes:	Magura HS11 Hydraulic rim brakes
Rear brakes:	Magura HS11 Hydraulic rim brakes
Options:	Various options available, please inquire with your dealer

Warranty

- Nijland Cycling provides a 5-year warranty on the frame and front fork
- A 2-year warranty applies to other components, as long as they are not subject to normal wear and tear
- Only the first owner is entitled to the warranty; it is not transferable

Warranty is not granted if:

- The bike has been used improperly or carelessly, or has been damaged in an accident
- Components are subject to normal wear, such as tires, cables, etc.
- The bike has not been maintained according to the instructions in this user manual
- Repairs have been carried out unprofessionally
- The construction of the bike has been modified

Other provisions

- You can only claim warranty if you can present the warranty certificate together with the purchase receipt

Warranty Certificate

This warranty certificate must be carefully completed and kept together with your proof of purchase for up to 5 years from the date of purchase.

- Bicycle details:
  Brand and model: _____
  Frame number: _____
  Date of purchase: _____

- Owner details: _____
  Name: _____
  Address: _____
  Postal code and city: _____

- Dealer details:
  Name: _____
  Address: _____
  Postal code and city: _____
  Phone number: _____

Service, Maintenance & Modifications Form

You can only claim warranty if your bicycle has undergone the service intervals listed below.

	Service:	Performed on:	Dealer initials:
	After first 200 km or 2 months		
	Service 1 years after delivery		
	Service 2 years after delivery		
	Service 3 years after delivery		
	Service 4 years after delivery		
	Service 5 years after delivery		

We recommend continuing with an annual service even after 5 years. Omitting this does not affect the warranty period, as the warranty expires after 5 years.

Modifications to the bicycle

	Modified:	Performed on:	Performed by:

Note! Only Nijland Cycling is authorized to perform modifications on this bicycle.

Maintenance History

Service:

Notes

Notes:

NIJLAND

Telgenweg 12
8111 CM Heeten

E: info@nijland.com
T: 0572-38 22 22

nijland.com